





Original	Replacement
 Power	 Power
 D/A Tv	 Smart
 Input	 AV
 Guide	 Guide
 Radio	 TV/R
 Subtitle*	 Subt
 PIP PR-	 Shift + Ch +
 PIP PR+	 Shift + Ch -
 Swap	 Media
 PIP Input	 Shift + AV
 PIP	 Shift + 3D
 Info	 Info
 Back	 Back
 ARC	 3D
 Menu	 Menu
 Text	 Text
 Exit	 Exit

Original	Replacement
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 FAV	 Pre Ch
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2





Original		Replacement	
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List
	Q.View		D. Menu
	[≡♦]/Size		Format
	[≡X]/Position		Eject
	[≡i]/Scan/Index		Shift + Info
	[≡o]/Time		Shift + Text
	[≡?]/Reveal		Options
	[≡+]/Hold		Shift + Subt
	I/II		Dual

Original		Replacement	
	Sleep		Sleep





Original	Replacement
Power	Power
Menu	Menu
Up	Up
OK	Ok
Down	Down
Right	Right
Left	Left
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Replacement
Play	Play
Pause	Pause
Stop	Stop
<<	<<
>>	>>
I<<	I<<
>>I	>>I





Original		Replacement	
	Power		Power
	Input		AV
	CH+		Ch +
	CH-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Play		Play
	Pause		Pause
	Stop		Stop

Original		Replacement	
	Rec		Rec
	<<		<<
	>>		>>

