







































































Original	Replacement	Original	Replacement
	Power		Power
	Input		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List
	Info		Info
	Vol+		Vol +
	Vol-		Vol -
	Mute / AD		Mute
	Mute / AD		Shift + Subt
	Home		Smart
	P+		Ch +
	P-		Ch -
	Back		Back
	Exit		Exit
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	Wheel Up		>>
	Wheel Down		<<
	OK		Ok
	Guide		Guide
	3D		3D
	*/Settings		Menu
	Red		Red



