






























































































Original	Replacement	Original	Replacement
 Power	 Power	 I<< Skip	 I<<
 PIP Audio	 3D	 Skip >>I	 >>I
 PIP	 Format	 Pause	 Pause
 Open/Close	 Eject	 Play	 Play
 1	 1	 Stop	 Stop
 2	 2	 Home	 Smart
 3	 3	 Disc menu	 D. Menu
 4	 4	 Return	 Back
 5	 5	 Display	 Info
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Enter	 Ok
 Clear	 Exit	 Audio	 Dual
 << Scan	 <<	 Subtitle	 Subt
 Scan >>	 >>	 On-Off	 Media





Original	Replacement	Original	Replacement
 Title/Pop-Up	 Options	 *	 List
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Marker	 Pre Ch		
 Search	 TV/R		
 Repeat	 Text		
 Zoom	 Shift + Eject		
 Tv Power	 Shift + Power		
 AV/Input Tv	 AV		
 PR/CH+ Tv	 Ch +		
 PR/CH- Tv	 Ch -		
 Vol+ Tv	 Vol +		
 Vol- Tv	 Vol -		
 Tv Mute	 Mute		
 Resolution	 Guide		

