




































































Original	Replacement	Original	Replacement
 Power	 Power	 XDSS plus	 Smart / List
 Mute	 Mute / Dimmer	 Sound Mode	 Sound / Title
 Tuner/Band	 Shift + 6	 Audio	 Audio / Lang I/II
 DVD	 Shift + 2	 Subtitle	 Subtitle / EQ
 Portable	 Shift + 3	 Return	 Back / Return
 USB	 Shift + 8	 Setup	 Setup / OPT /
 1	 1	 Up/Presets+	 Up
 2	 2	 Display	 Display / Media
 3	 3	 Left/Tun.-	 Left
 4	 4	 Select/Enter	 OK
 5	 5	 Right/Tun.+	 Right
 6	 6	 Menu	 Menu / Home
 7	 7	 Down/Presets-	 Down
 8	 8	 Title	 Shift + Sound / Title
 9	 9	 Prog. Memo	 TV/Radio /
 0	 0	 <</Scan-	 << / Tune-
 EQ	 Shift + Subtitle / EQ	 >>/Scan+	 >> / Tune+





Original	Replacement
Volume+	Vol+
Repeat	Green / APP / Repeat
</Slow-	CH- / Page-
>/Slow+	CH+ / Page+
Repeat A/B	Yellow / YouTube / Repeat
<</Skip-	<< / Preset-
>>/Skip+	>> / Preset+
Volume-	Vol-
Stop/Mo/ST	Stop / Hold
Pause/Step	Pause / Step / Freeze
Play	Play / Slow
Clear	Exit / Cancel / Clear
Zoom	Zoom / Size
Marker	Fav / Marker / PC
Search	Red / Netflix / Search
Sleep	Sleep / Timer
RDS	AV / Input / RDS

Original	Replacement
PTY	Picture / Format

