






















































































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 List	Menu Off	 Exit
Reveal	 Options	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	Chan.Up	 Ch +
Info	 Info	Volume-	 Vol -
Return TV	 +  Shift + Back	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Display	 +  Shift + Info	5	 5
Menu Up	 Up	6	 6
Menu Left	 Left	7	 7



Original	Replacement	Original	Replacement
8	 8	Store	 Smart
9	 9	Color+ P.Std	 +  Shift + Format
Guide -/-- 1.	 Guide	Search	 TV/R
0/10	 0	On/Off	 +  Shift + Power
2.Fav P/C 2.	 Pre Ch	AV 2	 +  Shift + AV
Red	 Red	Browse	 Media
Green	 Green	Tune-	 +  Shift + Left
Yellow	 Yellow	Aft/Caf	 +  Shift + Ok
Off/Tim	 Pause	Color- S.Std	 +  Shift + Dual
Bright+ Mode	 3D	Tune+	 +  Shift + Right
Store Text	 +  Shift + Smart	Contrast+	 +  Shift + Ch +
Blue	 Blue	Contrast-	 +  Shift + Ch -
Disp	 +  Shift + Media	3.*	 +  Shift + Guide
Tone-	 I<<	4.# 16:9	 Format
Mix Scan	 +  Shift + Text	Surround	 <<
Tone+	 >>I	Nicam/Mono	 Play
Audio+	 +  Shift + Up	Level L	 >>


























































Original	Replacement	Original	Replacement
On/Off	 Power	Menu Right	 Right
Mute	 Mute	Menu Off	 Exit
Update	 List	Display	 +  Shift + Info
Reveal	 Options	Menu Down	 Down
Info	 Info	Back	 Back
Subt.List	 Subt	Volume+	 Vol +
Txt Stop	 Stop	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 +  Shift + Back	Chan.Down	 Ch -
Menu video	 D. Menu	1	 1
Text	 Text	2	 2
Txt Expand	 Eject	3	 3
TV/AV	 AV	Menu audio	 Dual
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Menu Left	 Left	6	 6
OK Enter	 Ok	7	 7
































































Original	Replacement	
8		8
9		9
Guide -/-- 1.		Guide
0/10		0
2.Fav P/C 2.		Pre Ch
Red		<<
Tone+		>>
Bright+ Mode		3D
Green		Play
Audio-	 + 	Shift + Down
Store Text	 + 	Shift + Smart
Yellow		>>
Audio+	 + 	Shift + Up
Mix Scan	 + 	Shift + Text
Bright- Sys	 + 	Shift + 3D
Blue		Rec
On/Tim		Pause

Original	Replacement	
Game Coo	 + 	Shift + Options
Off/Tim	 + 	Shift + Pause
Store		Smart
Rotate Text	 + 	Shift + Mute
Tone-		<<
AV 2	 + 	Shift + AV
Disp	 + 	Shift + Media
Tune-	 + 	Shift + Left
Aft/Caf	 + 	Shift + Ok
Tune+	 + 	Shift + Right
Input	 + 	Shift + Vol +
Contrast+	 + 	Shift + Ch +
Color+ P.Std	 + 	Shift + Format
Browse		Media
Output	 + 	Shift + Vol -
Contrast-	 + 	Shift + Ch -
On Pip	 + 	Shift + 1
































Original	Replacement	Original	Replacement
Swap	 +  Shift + 2		
Rotate Pip	 +  Shift + 3		
Still	 +  Shift + 4		
Clear	 +  Shift + Exit		
Dim Pip	 +  Shift + 5		
Help	 +  Shift + 6		
Search	 TV/R		
Camera	 +  Shift + 7		
Camera1	 +  Shift + 8		
3.*	 +  Shift + Guide		
View	 +  Shift + 0		
4.# 16:9	 Format		
Surround	 +  Shift + <<		
Nicam/Mono	 +  Shift + Play		
Color- S.Std	 +  Shift + Dual		
Level L	 +  Shift + >>		
Level R/Woofers	 +  Shift + Rec		



Original	Replacement	Original	Replacement
On/Off	 Power	Display	 +  Shift + Info
Mute	 Mute	Menu Right	 Right
Update	 List	Menu Off	 Exit
Reveal	 Options	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 +  Shift + Back	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Menu Left	 Left	6	 6
OK Enter	 Ok	7	 7



Original	Replacement	
8		8
9		9
Guide -/-- 1.		Guide
0/10		0
2.Fav P/C 2.		Pre Ch
Red		<<
Bright+ Mode		3D
Green		Play
Off/Tim	 + 	Shift + Pause
Yellow		>>
Mix Scan	 + 	Shift + Text
On/Tim		Pause
Store Text	 + 	Shift + Smart
Color+ P.Std	 + 	Shift + Format
Blue		Rec
Rotate Text	 + 	Shift + Mute
AV 2	 + 	Shift + AV





































Original	Replacement	
Tune-	 + 	Shift + Left
Store		Smart
Audio-	 + 	Shift + Down
Disp		Media
Tune+	 + 	Shift + Right
Audio+	 + 	Shift + Up
Search		TV/R
Input	 + 	Shift + Vol +
Contrast+	 + 	Shift + Ch +
Output	 + 	Shift + Vol -
Contrast-	 + 	Shift + Ch -
On Pip	 + 	Shift + 1
Tone-		l<<
Tone+		>>l
Color- S.Std	 + 	Shift + Dual
Swap	 + 	Shift + 2
Still	 + 	Shift + 4













































Original	Replacement	Original	Replacement
Dim Pip	 +  Shift + 5		
Help	 +  Shift + 6		
Camera	 +  Shift + 7		
Camera1	 +  Shift + 8		
Clear	 +  Shift + Exit		
3.*	 +  Shift + Guide		
View	 +  Shift + 0		
4.# 16:9	 Format		
Nicam/Mono	 +  Shift + Play		
Level L	 +  Shift + >>		












Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 List	Menu Off	 Exit
Reveal	 Options	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	Menu audio	 Dual
Menu video	 D. Menu	Chan.Up	 Ch +
Info	 Info	Volume-	 Vol -
Text	 Text	Chan.Down	 Ch -
Txt Expand	 Eject	1	 1
Return TV	 +  Shift + Back	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 +  Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	
8		8
9		9
Guide -/-- 1.		Guide
0/10		0
2.Fav P/C 2.		Pre Ch
Red		<<
Green		Play
Yellow		>>
Blue		Rec
Rotate Text	 + 	Shift + Mute
Tone-		I<<
Bright+ Mode		3D
Disp	 + 	Shift + Media
Color+ P.Std	 + 	Shift + Format
Store Text	 + 	Shift + Smart
Bright- Sys	 + 	Shift + 3D
Audio-	 + 	Shift + Down

Original	Replacement	
Mix Scan	 + 	Shift + Text
Off/Tim	 + 	Shift + Pause
On/Tim		Pause
Audio+	 + 	Shift + Up
Game Coo	 + 	Shift + Eject
AV 2	 + 	Shift + AV
Store		Smart
Tune-	 + 	Shift + Left
Tune+	 + 	Shift + Right
Tone+		>>I
Search		TV/R
Aft/Caf	 + 	Shift + Ok
Browse		Media
Color- S.Std	 + 	Shift + Dual
Input	 + 	Shift + Vol +
Contrast+	 + 	Shift + Ch +
Output	 + 	Shift + Vol -



Original	Replacement	Original	Replacement
Contrast-	 +  Shift + Ch -		
On Pip	 +  Shift + 1		
Swap	 +  Shift + 2		
Rotate Pip	 +  Shift + 3		
Still	 +  Shift + 4		
Clear	 +  Shift + Exit		
Dim Pip	 +  Shift + 5		
Help	 +  Shift + 6		
Camera	 +  Shift + 7		
4.# 16:9	 Format		
Camera1	 +  Shift + 8		
3.*	 +  Shift + Guide		
View	 +  Shift + 0		
Surround	 +  Shift + <<		
Nicam/Mono	 +  Shift + Play		
Level L	 +  Shift + >>		
Level R/Woofers	 +  Shift + Rec		

