





























































| Original | | Replacement | | Original | | Replacement | |
|----------|------------|-------------|---------------|----------|-------------|-------------|--------|
| | Power 1 | | Power | | 5 | | 5 |
| | Power 2 | | Shift + Power | | 6 | | 6 |
| | Vol+ | | Vol + | | 7 | | 7 |
| | Vol- | | Vol - | | 8 | | 8 |
| | Phono | | Shift + 1 | | 9 | | 9 |
| | CD | | Shift + 2 | | 0 | | 0 |
| | Tuner | | Shift + 3 | | Mute | | Mute |
| | Tape 3/VCR | | Shift + 4 | | A. F/P | | Pre Ch |
| | TV1/AUX2 | | Shift + 5 | | B. -/-- | | Guide |
| | DVD | | Shift + 6 | | + | | Ch + |
| | Tape 1 | | Shift + 7 | | - | | Ch - |
| | Tape 2 | | Shift + 8 | | I<< | | I<< |
| | TV | | Shift + 9 | | >>I | | >>I |
| | 1 | | 1 | | Mode | | Format |
| | 2 | | 2 | | Memo | | 3D |
| | 3 | | 3 | | Text/1-Mode | | Text |
| | 4 | | 4 | | Time/Mode-2 | | AV |


































































| Original | Replacement | Original | Replacement |
|--|---|---|--|
|  Power 1 |  Power |  B. -/-- |  Guide |
|  Power 2 |  Shift + Power |  Play |  Play |
|  Vol+ |  Vol + |  >>I |  >>I |
|  Vol- |  Vol - |  I<< |  I<< |
|  Mute |  Mute |  >> |  >> |
|  1 |  1 |  << |  << |
|  2 |  2 |  Stop |  Stop |
|  3 |  3 |  Pause |  Pause |
|  4 |  4 |  Open/Close |  Eject |
|  5 |  5 |  Mode |  Format |
|  6 |  6 |  Memo |  3D |
|  7 |  7 |  Time/Mode-2 |  AV |
|  8 |  8 | | |
|  9 |  9 | | |
|  0 |  0 | | |
|  + |  Ch + | | |
|  A. F/P |  Pre Ch | | |





































































| Original | Replacement | Original | Replacement |
|---|---|---|--|
|  Power 1 |  Power |  + |  Ch + |
|  Power 2 |  Shift + Power |  - |  Ch - |
|  Vol+ |  Vol + |  Play |  Play |
|  Vol- |  Vol - |  >>I |  >>I |
|  1 |  1 |  I<< |  I<< |
|  2 |  2 |  Stop |  Stop |
|  3 |  3 |  Pause |  Pause |
|  4 |  4 |  Open/Close |  Eject |
|  5 |  5 |  >> |  >> |
|  6 |  6 |  << |  << |
|  7 |  7 |  Mode |  Format |
|  8 |  8 |  Memo |  3D |
|  9 |  9 |  Time/Mode-2 |  AV |
|  0 |  0 | | |
|  Mute |  Mute | | |
|  A. F/P |  Pre Ch | | |
|  B. -/-- |  Guide | | |





| | Original | Replacement | | Original | Replacement |
|---|----------|---|---|-------------|--|
|  | Power 1 |  Power |  | A. F/P |  Pre Ch |
|  | Power 2 |  Shift + Power |  | B. -/-- |  Guide |
|  | Vol+ |  Vol + |  | >>I |  >>I |
|  | Vol- |  Vol - |  | I<<< |  I<<< |
|  | Mute |  Mute |  | Play |  Play |
|  | 1 |  1 |  | <<< |  <<< |
|  | 2 |  2 |  | >>> |  >>> |
|  | 3 |  3 |  | Pause |  Pause |
|  | 4 |  4 |  | Stop |  Stop |
|  | 5 |  5 |  | Open/Close |  Eject |
|  | 6 |  6 |  | <> |  Rec |
|  | 7 |  7 |  | Mode |  Format |
|  | 8 |  8 |  | Memo |  3D |
|  | 9 |  9 |  | Text/1-Mode |  Text |
|  | 0 |  0 |  | Time/Mode-2 |  AV |
|  | + |  Ch + | | | |
|  | - |  Ch - | | | |

