





































| Original | Replacement |
|--|---|
|  Power |  Power |
|  3D |  3D |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Prog + |  Ch + |
|  Prog - |  Ch - |
|  Vol + |  Vol + |
|  Vol - |  Vol - |

| Original | Replacement |
|---|--|
|  Up / CH + |  Up |
|  Down / CH - |  Down |
|  Right / Vol + |  Right |
|  Left / Vol - |  Left |
|  OK |  Ok |
|  Menu |  Menu |
|  Info |  Info |
|  EPG |  Guide |
|  Exit |  Exit |
|  List |  List |
|  TXT |  Text |
|  S - T |  Dual |
|  TV / R |  TV/R |
|  Timer |  AV |
|  Audio |  Shift + Dual |
|  Play/Pause |  Play |
|  Stop |  Stop |





| Original | | Replacement | | Original | | Replacement | |
|---|--------------|---|--------|----------|--|-------------|--|
|  | Play/Pause |  | Pause | | | | |
|  | Rec |  | Rec | | | | |
|  | Back |  | Back | | | | |
|  | Red / << |  | Red | | | | |
|  | Red / << |  | << | | | | |
|  | Green / >> |  | Green | | | | |
|  | Green / >> |  | >> | | | | |
|  | Yellow / I<< |  | Yellow | | | | |
|  | Yellow / I<< |  | I<< | | | | |
|  | Blue / >>I |  | Blue | | | | |
|  | Blue / >>I |  | >>I | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

