



Original	Replacement	Original	Replacement
	Power		Power
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	PR+		Ch +
	PR-		Ch -
	Exit		Exit
	Back		Back
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Info		Info
	Menu		Menu
	Mute		Mute
	Source		AV
	Swap		Pre Ch
	0		0
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	EPG		Guide
	Text		Text
	FAV		Shift + Pre Ch





Original		Replacement		Original	Replacement
	Sleep		Sleep		
	Subtitle		Subt		
	Lang		Dual		
	Screen		Format		
	Presets		Eject		
	Internet		Smart		
	Multimedia		Media		
	Play		Play		
	My Button1		List		
	My Button2		D. Menu		
	Rec		Rec		
	Pause		Pause		
	Stop		Stop		
	>>		>>		
	<<		<<		
	>>		>>		
	<<		<<		

