





















	Original	Replacement		Replacement
	Phono		1	
	CD		2	
	Tuner		3	
	Aux		4	
	Tape1		5	
	Tape2		6	
	Vol+		Vol +	
	Vol-		Vol -	
	Mute		Mute	

	Original	Replacement		Replacement

