



Original	Replacement	Original	Replacement
 Power	 Power	 Dev.List	 List
 Mute	 Mute	 EPG	 Guide
 1	 1	 Subtitle	 Subt
 2	 2	 Text	 Text
 3	 3	 Auto	 Options
 4	 4	 Exit	 Exit
 5	 5	 Info	 Info
 6	 6	 Zoom	 Eject
 7	 7	 Menu	 Menu
 8	 8	 CH+	 Ch +
 9	 9	 CH-	 Ch -
 0	 0	 Up	 Up
 FAV	 Pre Ch	 Down	 Down
 Lang	 Dual	 Right	 Right
 HDMI	 Smart	 Left	 Left
 Tv/Radio	 TV/R	 Enter	 Ok
 Recall	 Back	 Vol+	 Vol +





	Original	Replacement	Original	Replacement
	Vol-	 Vol -		
	Filelist	 Format		
	Rec	 Rec		
	Stop	 Stop		
	Play	 Play		
	Pause	 Pause		
	<<	 <<		
	>>	 >>		
	<<	 <<		
	>>	 >>		
	Red	 Red		
	Green	 Green		
	Yellow	 Yellow		
	Blue	 Blue		

