















Original	Replacement	Original	Replacement
Power	Power	Blue/[]	Blue
Vol+	Vol +	Info	Info
Vol-	Vol -	Text	Text
PR+	Ch +	1	1
PR-	Ch -	2	2
Mute	Mute	3	3
Menu	Menu	4	4
Exit	Exit	5	5
Back	Back	6	6
OK	Ok	7	7
Up	Up	8	8
Down	Down	9	9
Right/Zoom+	Right	0/-/--	0
Left/Zoom-	Left	AV	AV
Red/[o]	Red	SP/LP	Media
Green/Timer/List	Green	Play	Play
Yellow	Yellow	>>	>>





Original	Replacement	Original	Replacement
 REV	<<		<<
 STOP	Stop		Stop
 PAUSE	Pause		Pause
 REC	Rec	 REC MODE	Rec
 MARK	Mark	 ECO 3D	3D
 0000	0000	 -/-- GUIDE	Guide











Original	Replacement	Original	Replacement
	Power		Blue/[]
	Vol +		Info
	Vol -		Text
	Mute		Play
	Ch +		Stop
	Ch -		Rec
	Exit		Pause
	Menu		>>
	Back		<<
	Up		1
	Down		2
	Right		3
	Left		4
	Ok		5
	Red		6
	Green		7
	Yellow		8





Original		Replacement		Original		Replacement	
	9		9				
	AV		AV				
	SP/LP		Media				

















Original	Replacement	Original	Replacement
	Power		Blue/[]
	Vol +		Info
	Vol -		Text
	Mute		1
	Ch +		2
	Ch -		3
	Menu		4
	Exit		5
	Back		6
	Up		7
	Down		8
	Right		9
	Left		0
	Ok		AV
	Red		Media
	Green		Play
	Yellow		Stop





	Original	Replacement	Original	Replacement
	>>	 >>		
	<<	 <<		
	Rec	 REC MODE Rec		
	Pause	 Pause		
	Mark	 ECO 3D 3D		
	0000	 -/-- GUIDE Guide		

