



















































































































Original	Replacement	Original	Replacement
 Power	 Power	 CH+	 Ch +
 Auto/Eject	 Smart	 CH-	 Ch -
 Mute	 Mute	 Aspect	 Format
 1	 1	 D.Disp	 Media
 2	 2	 Display	 Info
 3	 3	 Enter	 Ok
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 LCD Menu	 Menu
 9	 9	 Exit/DVD Setup	 Exit
 0	 0	 Input	 AV
 -/--	 Shift + Guide	 P-Mode	 Shift + Format
 Recall	 Pre Ch	 S.Mode	 Shift + Dual
 Vol-	 Vol -	 Sleep	 Sleep
 Vol+	 Vol +	 FAV	 Shift + Pre Ch





Original	Replacement
 Play/Pause	 Play
 Stop	 Stop
 FAV-	 Shift + Ch -
 FAV+	 Shift + Ch +
 EPG	 Guide
 I<<	 I<<
 Text	 Text
 <<	 <<
 Hold	 Options
 >>I	 >>I
 Audio/Lang	 Dual
 Subtitle	 Subt
 Index	 TV/R
 Angle/Reveal	 Shift + Options
 D.Menu	 D. Menu
 Nicam	 Shift + Smart
 Title	 List

Original	Replacement
 Goto	 Eject
 Red/Prog	 Red
 Green/Intro	 Green
 Zoom/Subpage	 3D
 Yellow/Repeat	 Yellow
 Blue/A-B	 Blue
 >>/Aspect	 >>
 I>	 Pause

