













































Original	Replacement	Original	Replacement
	Power		Power
	Input		AV
	TV/TXT		Text
	Cancel		Eject
	Reveal		Media
	Nicam/A2		Dual
	Hold		Options
	Size		Format
	Subpage		D. Menu
	Index		Smart
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	CH+		Ch +
	CH-		Ch -
	Menu		Menu
	Exit		Exit
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Channel List		TV/R
	EPG		Guide
	Info		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	1		1
	2		2
	3		3
	4		4
	5		5





Original	Replacement
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 FAV	 Pre Ch
 Picture	 Shift + Format
 Sound	 Shift + Dual
 Recall	 Back
 Sleep	 Sleep
 Subtitle	 Subt
 Aspect	 3D
 Rec	 Rec
 <<	 <<
 >>	 >>
 List	 List
 I<<	 I<<

Original	Replacement
 >>I	 >>I
 Repeat	 Shift + Text
 Play	 Play
 Pause	 Pause
 Stop	 Stop

