Mandis shop

POLK-AUDIO 981307102280K

Original		Replacement	
Power	Power	Power	
1	HDMI 1	TV 1	1
2	HDMI 2	DVD 2	2
3	HDMI 3	CD-STB 3	3
TV	TV	PROGRAM TV/RADIO	TV/Radio /
Bluetooth	Bluetooth	BLUETOOTH 9	9
BASS+	Bass+		Up
VOL+	Vol +	VOL+	Vol +
VOICE+	Voice+	CH PAGE+	CH+ / Page+
BASS-	Bass-		Down
VOL-	Vol -	VOL-	Vol -
VOICE-	Voice-	CH PAGE-	CH- / Page-
Mute	Mute	DIMMER MUTE	Mute / Dimmer
MOVIE	Movie	EQ SUBTITLE	Subtitle / EQ
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II
NIGHT	Night	CLEAR EXIT CANCEL	Exit / Cancel / Clear
3D	3D	FORMAT PICTURE	Picture / Format

Original		Replacement	
SPORT	Sport	RETURN BACK	Back / Return
VOLUME SURROUND-	Volume Surround-	SHIFT + VOL-	Shift + Vol -
VOLUME SURROUND+	Volume	SHIFT + VOL+	Shift + Vol +
BALANCE L	Balance L		Left
BALANCE R	Balance R		Right

https://telecomandi-mandis.it/en/POLK-AUDIO-981307102280K-replacement-remote-control-for-POLK-AUDIO-981307102280K.htm