







































































Original	Replacement	Original	Replacement
	Power		Power
	Stop		Stop
	Pause		Pause
	<<		<<
	Play		Play
	>>		>>
	>		>>
	<		<<
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Find		TV/R
	Adjust		Menu
	Home		Smart
	Back		Back
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Source		AV
	Options		Options
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6





Original	Replacement	Original	Replacement

