









| Original  | Replacement   | Original   | Replacement   |
|---|---|--|---|
|  Power     |  Power       |  --       |  Guide / EPG / -/--            |
|  Up / P+   |  Up          |  0        |  0                             |
|  Up / P+   |  CH+ / Page+ |  P < P    |  Fav / Marker / PC             |
|  Menu      |  Menu / Home |  PP       |  Back / Return                 |
|  Left      |  Left        |  Vol+     |  Vol+                          |
|  Right     |  Right       |  I-II     |  Audio / Lang I/II             |
|  Down / P- |  Down        |  Mute     |  Mute / Dimmer                 |
|  Down / P- |  CH- / Page- |  Vol-     |  Vol-                          |
|  1         |  1           |  Info     |  Info / Angle                  |
|  2        |  2          |  Red     |  Red / Netflix / Search       |
|  3       |  3         |  Green  |  Green / APP / Repeat        |
|  4       |  4         |  Yellow |  Yellow / YouTube / Repeat   |
|  5       |  5         |  Blue   |  Blue / Prime Video / Random |
|  6       |  6         |  [TV]   |  Shift + 1                   |
|  7       |  7         |  [TV]   |  TV/Radio /                  |
|  8       |  8         |  [AV]   |  AV / Input / RDS            |
|  9       |  9         |  [ ≡ ]  |  Text / Goto                 |











































| Original  | Replacement   |
|---|---|
|  Power     |  Power       |
|  Up / P+   |  Up          |
|  Up / P+   |  CH+ / Page+ |
|  Menu      |  Menu / Home |
|  Left      |  Left        |
|  Select    |  OK          |
|  Right     |  Right       |
|  Down / P- |  CH- / Page- |
|  Down / P- |  Down        |
|  1        |  1          |
|  2       |  2         |
|  3       |  3         |
|  4       |  4         |
|  5       |  5         |
|  6       |  6         |
|  7       |  7         |
|  8       |  8         |



































| Original   | Replacement   |
|--|---|
|  9        |  9                             |
|  +10      |  Guide / EPG / -/-             |
|  0        |  0                             |
|  Repeat   |  Green / APP / Repeat          |
|  Search   |  Red / Netflix / Search        |
|  A→B      |  Yellow / YouTube / Repeat     |
|  Display  |  Display / Media               |
|  Audio    |  Audio / Lang I/II             |
|  Subtitle |  Subtitle / EQ                 |
|  Zoom    |  Zoom / Size                  |
|  Prog   |  TV/Radio /                  |
|  C      |  Blue / Prime Video / Random |
|  Angle  |  Info / Angle                |
|  Return |  Back / Return               |
|  Time   |  Sleep / Timer               |
|  <<     |  << / Tune-                  |
|  >>     |  >> / Tune+                  |









| Original    | Replacement   | Original   | Replacement   |
|-------------|---|------------|---|
| On/Off      |  Power             | Menu Right |  Right           |
| Mute        |  Mute / Dimmer     | Menu Down  |  Down            |
| Txt Stop    |  Stop / Hold       | Back       |  Back / Return   |
| Tone+       |  >> / Tune+        | Volume+    |  Vol+            |
| Lang        |  Sound / Title     | Chan.Up    |  CH+ / Page+     |
| Menu audio  |  Audio / Lang I/II | Volume-    |  Vol-            |
| Subt.List   |  Subtitle / EQ     | Display    |  Display / Media |
| Txt Expand  |  Zoom / Size       | Chan.Down  |  CH- / Page-     |
| Sleep Timer |  Sleep / Timer     | 1          |  1               |
| Return TV   |  TV/Radio /        | 2          |  2               |
| Menu video  |  D.Menu / Top     | 3          |  3              |
| Text        |  Text / Goto     | 4          |  4             |
| Menu        |  Menu / Home     | 5          |  5             |
| Menu Up     |  Up              | 6          |  6             |
| Info        |  Info / Angle    | 7          |  7             |
| Menu Left   |  Left            | 8          |  8             |
| OK Enter    |  OK              | 9          |  9             |



