































| Original | | Replacement | | Original | | Replacement | |
|---|------------|---|--------|---|----------|---|---------|
|  | Power |  | Power |  | Recall |  | Back |
|  | Mute |  | Mute |  | Text |  | Text |
|  | Red |  | Red |  | Subtitle |  | Subt |
|  | Blue/Pause |  | Blue |  | USB |  | AV |
|  | Green |  | Green |  | Menu |  | Menu |
|  | Yellow |  | Yellow |  | Exit |  | Exit |
|  | Audio |  | Dual |  | EPG |  | Guide |
|  | Zoom |  | Eject |  | FAV |  | Pre Ch |
|  | Info |  | Info |  | Up |  | Up |
|  | << |  | << |  | Down |  | Down |
|  | >> |  | >> |  | Right |  | Right |
|  | I<< |  | I<< |  | Left |  | Left |
|  | >>I |  | >>I |  | OK |  | Ok |
|  | Play |  | Play |  | Find |  | Options |
|  | Stop |  | Stop |  | SAT |  | Format |
|  | Rec |  | Rec |  | HDMI |  | Smart |
|  | Pause |  | Pause |  | F1 |  | Media |





| Original | Replacement | Original | Replacement |
|--|---|----------|-------------|
|  Page+ |  Ch + | | |
|  Page- |  Ch - | | |
|  1 |  1 | | |
|  2 |  2 | | |
|  3 |  3 | | |
|  4 |  4 | | |
|  5 |  5 | | |
|  6 |  6 | | |
|  7 |  7 | | |
|  8 |  8 | | |
|  9 |  9 | | |
|  0 |  0 | | |
|  Sleep |  Sleep | | |
|  TV/Radio |  TV/R | | |
| | | | |
| | | | |
| | | | |

