



Original	Replacement
 Power	 Power
 Input	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Info	 Info / Angle
 0	 0
 EPG	 Guide / EPG / -/-
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 Menu	 Menu / Home

Original	Replacement
 P+	 CH+ / Page+
 Vol-	 Vol-
 APP	 Shift + Green / APP /
 P-	 CH- / Page-
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 X/Exit	 Exit / Cancel / Clear
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Audio	 Audio / Lang I/II
 [...] / Sub	 Subtitle / EQ





Original

Replacement

	Text		Text / Goto
	Rad/Tv		TV/Radio /
	List		Smart / List
	SAT	+	Shift + 0

Original

Replacement

