







































































Original	Replacement	Original	Replacement
 Power	 Power	 S.Mode	 Shift + Dual
 Mute	 Mute	 Source	 AV
 1	 1	 Prog+	 Ch +
 2	 2	 Prog-	 Ch -
 3	 3	 Exit	 Exit
 4	 4	 Menu	 Menu
 5	 5	 Up	 Up
 6	 6	 Down	 Down
 7	 7	 Right	 Right
 8	 8	 Left	 Left
 9	 9	 OK	 Ok
 0	 0	 Zoom	 Eject
 PR.List	 List	 Sleep	 Sleep
 Recall	 Back	 DNR	 Media
 Vol+	 Vol +	 MTS	 Smart
 Vol-	 Vol -	 Red	 Red
 Pic Mode	 Shift + Format	 Green	 Green





Original		Replacement		Original	Replacement
	Yellow		Yellow		
	Blue		Blue		
	FAV		Pre Ch		
	Tv/Radio		TV/R		
	Audio		Dual		
	Subtitle		Subt		
	Size		Format		
	Reveal		Options		
	EPG		Guide		
	Info		Info		
	Text		Text		
	Index		D. Menu		
	Subpage		Shift + Subt		
	Hold		3D		

