







































































Original	Replacement	Original	Replacement
	Power		Power
	3D		3D
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Timer		AV
	Audio		Dual
	Menu		Menu
	Info		Info
	EPG		Guide
	Exit		Exit
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Vol +		Vol +
	Vol -		Vol -
	Prog -		Ch -
	Prog +		Ch +
	Liste		List
	TXT		Text
	S-T		Subt
	TV / R		TV/R
	Play / Pause		Play
	Play / Pause		Pause



