




| Original  | Replacement | Original  | Replacement                |
|---|-------------|---|----------------------------|
|      | Power       |      | Power                      |
|      | Mute        |      | Mute / Dimmer              |
|      | 1           |      | 1                          |
|      | 2           |      | 2                          |
|      | 3           |      | 3                          |
|      | 4           |      | 4                          |
|      | 5           |      | 5                          |
|      | 6           |      | 6                          |
|      | 7           |      | 7                          |
|     | 8           |     | 8                          |
|    | 9           |    | 9                          |
|    | -/--        |    | Shift + Guide / EPG / -/-- |
|    | 0           |    | 0                          |
|    | Recall      |    | Back / Return              |
|    | P.Mode      |    | Picture / Format           |
|    | S.Mode      |    | Sound / Title              |
|    | FAV         |    | Fav / Marker / PC          |
|    | Vol+        |    | Vol+                       |
|    | MTS I/II    |    | Audio / Lang I/II          |
|    | CH+         |    | CH+ / Page+                |
|    | Vol-        |    | Vol-                       |
|    | Sub-T       |    | Subtitle / EQ              |
|    | CH-         |    | CH- / Page-                |
|    | Aspect      |    | Shift + Picture / Format   |
|    | Freeze      |    | Shift + Pause / Step /     |
|    | Sleep       |    | Sleep / Timer              |
|   | Source      |   | AV / Input / RDS           |
|  | Up          |  | Up                         |
|  | Display     |  | Display / Media            |
|  | Left        |  | Left                       |
|  | OK          |  | OK                         |
|  | Right       |  | Right                      |
|  | Menu        |  | Menu / Home                |
|  | Down        |  | Down                       |





| Original |              | Replacement |                              | Original |         | Replacement |                    |
|----------|--------------|-------------|------------------------------|----------|---------|-------------|--------------------|
|          | Exit         |             | Exit / Cancel / Clear        |          | List    |             | Smart / List       |
|          | Red          |             | Red / Netflix / Search       |          | T.Shift |             | TV/Radio /         |
|          | Green        |             | Green / APP / Repeat         |          | USB     |             | Shift + 8          |
|          | Yellow       |             | Yellow / YouTube / Repeat    |          | EPG     |             | Guide / EPG / -/-- |
|          | Blue         |             | Blue / Prime Video / Random  |          |         |             |                    |
|          | << / Text/CC |             | << / Tune-                   |          |         |             |                    |
|          | << / Text/CC |             | Text / Goto                  |          |         |             |                    |
|          | Play/Pause / |             | Play / Slow                  |          |         |             |                    |
|          | Play/Pause / |             | Pause / Step / Freeze        |          |         |             |                    |
|          | >> / Reveal  |             | >> / Tune+                   |          |         |             |                    |
|          | <<< / Hold   |             | <<< / Preset-                |          |         |             |                    |
|          | <<< / Hold   |             | Shift + Stop /               |          |         |             |                    |
|          | >>>   / Size |             | >>>   / Preset+              |          |         |             |                    |
|          | >>>   / Size |             | Zoom / Size                  |          |         |             |                    |
|          | Stop / Index |             | Stop / Hold                  |          |         |             |                    |
|          | Root         |             | Info / Angle                 |          |         |             |                    |
|          | Repeat       |             | Shift + Green / APP / Repeat |          |         |             |                    |

