










































































Original	Replacement
 Power	 Power
 Open/Close	 Eject / Surround
 Source/Function	 AV / Input / RDS
 Vol-	 Vol-
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 1/RDS Display	 1
 2	 2
 3/TA	 3
 4/PTY-	 4
 5/PTY Search	 5
 6/PTY+	 6
 7	 7
 8	 8
 9	 9
 Disc Menu	 D.Menu / Top
 0	 0

Original	Replacement
 Popup/Title Menu	 Smart / List
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Subtitle	 Subtitle / EQ
 Home	 Menu / Home
 Repeat	 Shift + Green / APP / REPEAT
 Tools	 Setup / OPT /
 Up	 Up
 Info	 Info / Angle
 Left	 Left
 Enter	 OK
 Right	 Right





Original	Replacement
 Return	 Back / Return
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Red/A	 Red / Netflix / Search
 Green/B	 Green / APP / Repeat
 Yellow/C/Tuner Memory	 Yellow / YouTube / Repeat
 Blue/D/MO/ST	 Blue / Prime Video / Random
 Tv Sound	 Sound / Title
 DSP/EQ	 Audio / Lang I/II
 DSP/EQ	 Shift + Subtitle / EQ
 DOWN Tuning Down	 CH- / Page-
 DOWN Tuning Down	 Shift + << /
 UP Tuning Up	 CH+ / Page+
 UP Tuning Up	 Shift + >> /

Original	Replacement

