







































































Original		Replacement		Original		Replacement	
	Power		Power		<<		<<
	Open/Close		Eject		>>		>>
	Zoom		Shift + Eject		l<<		l<<
	1		1		Stop		Stop
	2		2		Play		Play
	3		3		Pause		Pause
	4		4		>>l		>>l
	5		5		Menu		Menu
	6		6		Return		Back
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	Video Sel		Smart		Enter		Ok
	Step		Guide		Disc Menu		D. Menu
	I.Replay		Options		EZ View		3D
	I.Skip		TV/R		Info		Info



