







































































Original		Replacement		Original		Replacement	
	Power		Power		?/Help		Options
	TV		TV/R		Menu		Menu
	Video		Smart		P+		Ch +
	↑/CH Scan		Media		P-		Ch -
	PRE-CH		Back		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		→/ ←/P.STD		Format
	3		3		Sleep		Sleep
	4		4		Zoom		Eject
	5		5		Mute		Mute
	6		6		→/ ←/S.STD		D. Menu
	7		7		O/I/II/S.Mode		Dual
	8		8		Red		Red
	9		9		Green		Green
	0		0		Yellow		Yellow
	-/-		Guide		Blue		Blue
	[+]/[=]/Display		Info		[≡]		List



