























































| Original  |       | Replacement   |                  | Original  |               | Replacement   |                       |
|---|-------|---|------------------|---|---------------|---|-----------------------|
|    | Power |    | Power            |  | ATR           |  | D.Menu / Top          |
|    | Clock |    | Sleep / Timer    |  | <<            |  | << / Tune-            |
|    | 1     |    | 1                |  | Play          |  | Play / Slow           |
|    | 2     |    | 2                |  | >>            |  | >> / Tune+            |
|    | 3     |    | 3                |  | Rec           |  | Rec / Rec Mode        |
|    | Prog  |    | TV/Radio /       |  | Stop          |  | Stop / Hold           |
|    | 4     |    | 4                |  | Pause / Still |  | Pause / Step / Freeze |
|    | 5     |    | 5                |  | Index         |  | Info / Angle          |
|    | 6     |    | 6                |  | Reset         |  | Exit / Cancel / Clear |
|    | CL    |    | Menu / Home      |  | Memory        |  | Text / Goto           |
|  | 7     |  | 7                |   |               |   |                       |
|  | 8     |  | 8                |   |               |   |                       |
|  | 9     |  | 9                |   |               |   |                       |
|  | -     |  | CH- / Page-      |   |               |   |                       |
|  | 0/AV  |  | AV / Input / RDS |   |               |   |                       |
|  | 0/AV  |  | 0                |   |               |   |                       |
|  | +     |  | CH+ / Page+      |   |               |   |                       |

