











































































Original	Replacement	Original	Replacement
 Power Tv	 Power	 ←	 Shift + Left
 NET	 Media	 →	 Shift + Right
 [i+]	 Info	 Pause	 Pause
 FAV	 Shift + Pre Ch	 1	 1
 ATV	 Smart	 2	 2
 DTV	 D. Menu	 3	 3
 SAT	 Shift + Media	 4	 4
 Radio	 TV/R	 5	 5
 Power Source	 Shift + Power	 6	 6
 << Source	 Shift + <<	 7	 7
 Play Source	 Play	 8	 8
 >> Source	 Shift + >>	 9	 9
 USB Rec	 Shift + Rec	 0	 0
 Rec Source	 Rec	 Recall	 Pre Ch
 Rec Stop	 Shift + Stop	 Source	 AV
 Stop Source	 Stop	 I/II/I+II/▼/O	 Dual
 Ready/Time Shift	 Options	 [<>]	 Format





Original		Replacement		Original		Replacement	
	AV Mode		Shift + AV		OK		Ok
	Eco		Shift + 3D		>>		>>
	Vol+		Vol +		<<		<<
	Vol-		Vol -		>>		>>
	Mute		Mute		<<		<<
	P+		Ch +		[...]		Subt
	P-		Ch -		[≡?]		List
	[≡]		Text		[≡o]		Sleep
	3D		3D		[≡+]		Eject
	End		Exit		Red		Red
	EPG		Guide		Green		Green
	Back		Back		Yellow		Yellow
	Menu		Menu		Blue		Blue
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				

