





































Original	Replacement	Original	Replacement
	Power		Power
	TV/VTR		TV/Radio /
	Eject		Eject / Surround
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide / EPG / -/--
	Prog+		CH+ / Page+
	Prog-		CH- / Page-
	Vol+		Vol+
	Vol-		Vol-
	Play		Play / Slow
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Search >>		>> / Tune+
	Index Search >>		>>  / Preset+
	I<< Index Search		I<< / Preset-
	X2		Smart / List
	<< Search		<< / Tune-
	Skip		Exit / Cancel / Clear
	Wheel >/Frame		Shift + >>  / Preset+
	Up		Up
	< Wheel/<		Shift + I<< / Preset-
	Down		Down
	Right		Right
	Left		Left
	Menu		Menu / Home







Original	Replacement	Original	Replacement
	Power		CH- / Page-
	Display		Audio / Lang I/II
	TV/Radio /		Red / Netflix / Search
	1		Green / APP / Repeat
	2		Yellow / YouTube / Repeat
	3		Blue / Prime Video / Random
	4		Text / Goto
	5		Smart / List
	6		
	7		
	8		
	9		
	0		
	Guide / EPG / -/--		
	Vol+		
	Vol-		
	CH+ / Page+		

