



	Original	Replacement	Original	Replacement
		 Smart / List		
		 Power		
		 CH+ / Page+		
		 Red / Netflix / Search		
		 I<< / Preset-		
		 >>I / Preset+		
		 CH- / Page-		
		 << / Tune-		
		 Play / Slow		
		 >> / Tune+		
		 Pause / Step / Freeze		
		 Stop / Hold		
		 Shift + Play /		
		 Right		
		 Green / APP / Repeat		
		 Display / Media		

