



Original	Replacement
Mult	Smart / List
Search	Red / Netflix / Search
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Esc	Exit / Cancel / Clear
0	0
-/--	Guide / EPG / -/--
Up	Up
Left	Left
Menu	Menu / Home

Original	Replacement
Right	Right
ADD	Fav / Marker / PC
Down	Down
FN	Info / Angle
I<	I<< / Preset-
I>	Pause / Step / Freeze
</	CH- / Page-
>>	>> / Tune+
>	>> / Preset+
Rec	Rec / Rec Mode
>/	CH+ / Page+

