







































































Original	Replacement	Original	Replacement
 Input	 AV / Input / RDS	 P+	 CH+ / Page+
 Power	 Power	 Vol-	 Vol-
 Mute	 Mute / Dimmer	 P-	 CH- / Page-
 1	 1	 [i+]	 Info / Angle
 2	 2	 Up	 Up
 3	 3	 Guide	 Guide / EPG / -/--
 4	 4	 Left	 Left
 5	 5	 OK	 OK
 6	 6	 Right	 Right
 7	 7	 Back	 Back / Return
 8	 8	 Down	 Down
 9	 9	 Exit	 Exit / Cancel / Clear
 Lang	 Audio / Lang I/II	 Red	 Red / Netflix / Search
 0	 0	 Green	 Green / APP / Repeat
 TXT	 Text / Goto	 Yellow	 Yellow / YouTube / Repeat
 Vol+	 Vol+	 Blue	 Blue / Prime Video / Random
 Home	 Menu / Home	 Prime Video	 Shift + Blue / Prime Video / Random





Original	Replacement	Original	Replacement
 Netflix	 Shift + Red / Netflix /		
 You Tube	 Shift + Yellow / YouTube /		
 twitch	 Smart / List		
 Rakuten Tv	 Shift + Green / APP /		
 *1	 Setup / OPT /		
			
 Pause	 Pause / Step / Freeze		
			
 Rec	 Rec / Rec Mode		
 Play	 Play / Slow		
 Stop	 Stop / Hold		

Original	Replacement	Original	Replacement

