




































































Original	Replacement	Original	Replacement
	Source		AV
	Power		Power
	TV		TV/R
	-[/]-		Sleep
	[<>]		Format
	O)I/II		Dual
	Subtitle		Subt
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	AD		Shift + Subt
	0		0
	Recall		Pre Ch
	Vol+		Vol +
	[i+]		Info
	P+		Ch +
	Vol-		Vol -
	Mute		Mute
	P-		Ch -
	Quick		Smart
	[.]		Shift + Options
	[>]		Options
	Text		Text
	List		List
	Menu		Menu
	↑ ↑		Shift + Up
	Guide		Guide
	Up		Up





Original	Replacement	Original	Replacement
 <<	 +  Shift + Left	 Green	 Green
 Left	 Left	 Yellow	 Yellow
 OK	 Ok	 Blue	 Blue
 Right	 Right		
 >>	 +  Shift + Right		
 Back	 Back		
 Down	 Down		
 Exit	 Exit		
 ↓↓	 +  Shift + Down		
 <</[≡+]	 <<		
 Play	 Play		
 >>/[≡◇]	 >>		
 I<</[≡?]	 I<<		
 Stop	 Stop		
 Pause/Step	 Pause		
 >>I/[O]/[≡x]	 >>I		
 Red	 Red		

