















































Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 1	 1
 2	 2
 3	 3
 3D	 Picture / Format
 4	 4
 5	 5
 6	 6
 Mode	 D.Menu / Top
 7	 7
 8	 8
 9	 9
 Zoom	 Zoom / Size
 Timer	 Sleep / Timer
 0	 0
 [ + ]	 Info / Angle

Original	Replacement
 Normal	 Smart / List
 Input	 AV / Input / RDS
 Up	 Up
 PR+	 CH+ / Page+
 OK [=i]	 OK
 Left	 Left
 Vol-	 Vol-
 Menu	 Menu / Home
 Right	 Right
 Vol+	 Vol+
 [=x]	 Subtitle / EQ
 PR-	 CH- / Page-
 Down	 Down
 [=]	 Text / Goto
 [=+]	 Setup / OPT /
 [=o]	 Audio / Lang I/II
 [=?]	 Display / Media





Original	Replacement	Original	Replacement
 [= ◆]	 TV/Radio /		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		

