
























































	Original	Replacement		Original	Replacement
	Power		Power		Rec
	Home		Smart		Rec
	1		1		Stop
	2		2		Pause
	3		3		Play
	4		4		Vol +
	5		5		Vol -
	6		6		Setup
	7		7		Options
	8		8		I<< Prev
	9		9		>>I Next
	0		0		<< FR
	Goto		List		>> FF
	Mute		Mute		Up
	Display		Info		Left
	Audio		Dual		Enter
	Subtitle		Subt		Right
					Down
					Browser
					Media





Original		Replacement		Original		Replacement	
	Return		Back				
	Red / Slow		Red				
	Green / TimeShift		Green				
	Yellow / CM Skip		Yellow				
	Blue / Replay		Blue				
	Repeat		Text				
	Zoom		Eject				
	Copy		3D				
	TV System		TV/R				
	Source		AV				
	EPG		Guide				
	Edit		Format				
	Timer	 + 	Shift + AV				

