




















































































| Original | Replacement | Original | Replacement |
|---|-------------|---|-----------------------|
|  | Power |  | Power |
|  | Mute |  | Mute / Dimmer |
|  | Play |  | Play / Slow |
|  | Pause |  | Pause / Step / Freeze |
|  | Stop |  | Stop / Hold |
|  | Rec |  | Rec / Rec Mode |
|  | << |  | << / Tune- |
|  | l<< |  | l<< / Preset- |
|  | >>l |  | >>l / Preset+ |
|  | >> |  | >> / Tune+ |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Info |  | Info / Angle |
|  | EPG |  | Guide / EPG / -/- |
|  | ≡ |  | Menu / Home |
|  | Source |  | AV / Input / RDS |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Exit |  | Exit / Cancel / Clear |
|  | Smart |  | Smart / List |
|  | ← |  | Back / Return |
|  | Vol+ |  | Vol+ |
|  | P+ |  | CH+ / Page+ |





| Original | Replacement |
|--|---|
|  Vol- |  Vol- |
|  Home |  Shift + Menu / |
|  P- |  CH- / Page- |
|  Netflix |  Shift + Red / Netflix / |
|  You Tube |  Shift + Yellow / YouTube / |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  O)I/I |  Audio / Lang I/II |
|  [=] |  Text / Goto |
|  Subt. |  Subtitle / EQ |
| | |
| | |
| | |
| | |
| | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

