







































































Original		Replacement		Original		Replacement	
	Power		Power		Left		Left
	Mute		Mute		OK/List		Ok
	1		1		PR+		Ch +
	2		2		PR-		Ch -
	3		3		Vol+		Vol +
	4		4		Vol-		Vol -
	5		5		P+/↑		>>
	6		6		P-/↓		<<
	7		7		EPG		Guide
	8		8		Info		Info
	9		9		SAT		Smart
	0		0		Tv/Radio		TV/R
	Menu		Menu		Multi Pict		Format
	Exit		Exit		←PR		Back
	Up		Up		FAV		Pre Ch
	Down		Down		Audio		Dual
	Right		Right		Red/Text		Red



