





































































Original	Replacement	Original	Replacement
 Power	 Power	 List	 List
 Mute	 Mute	 Recall	 Back
 Source	 AV	 Tv Menu	 Menu
 P.Mode	 Shift + Format	 Exit	 Exit
 S.Mode	 Shift + Dual	 Text	 Text
 I/II/Audio	 Dual	 Info/Display	 Info
 Sleep	 Sleep	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 OK/Enter	 Ok
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 P+	 Ch +
 8	 8	 P-	 Ch -
 9	 9	 Red	 Red
 0	 0	 Green	 Green





Original		Replacement		Original	Replacement
	Yellow		Yellow		
	Blue		Blue		
	Subtitle		Subt		
	Hold		Options		
	Size		Format		
	Reveal		Smart		
	Mix		Media		
	Zoom/Index		Eject		
	FAV		Pre Ch		
	Subpage		3D		
	Tv/Radio		TV/R		
	EPG		Guide		

