






Original	Replacement	Original	Replacement
 Power	 Power	 Info	 Info
 Mute	 Mute	 Menu	 Menu
 1	 1	 Exit	 Exit
 2	 2	 Text	 Text
 3	 3	 EPG	 Guide
 4	 4	 Up/CH+	 Up
 5	 5	 Down/CH-	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 Enter	 Ok
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 FAV	 Pre Ch	 Stop	 Stop
 Recall	 Back	 Play	 Play
 Lang	 Dual	 Rec	 Rec
 Tv/Radio	 TV/R	 Pause	 Pause
 Dev.List	 List	 <<	 <<





	Original	Replacement		Original	Replacement
			>>		
			I<<		
			>>I		
			Page Up		
			Page Down		
			HDMI		
			Zoom		
			Subtitle		
			Filelist		
			Goto		
			Repeat		
			Timeshift		
			Auto		
			Red		
			Green		
			Yellow		
			Blue		

