































































































| Original | Recharge | Original | Recharge |
|---|----------|---|-----------------------------|
|  | Power |  | Power |
|  | DTV |  | Shift + TV/Radio / Program |
|  | TV |  | TV/Radio / |
|  | AV |  | AV / Input / RDS |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | Text |  | Text / Goto |
|  | 0 |  | 0 |
|  | PRE-CH |  | Back / Return |
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | Vol+ |  | Vol+ |
|  | i |  | Info / Angle |
|  | CH+ |  | CH+ / Page+ |
|  | Vol- |  | Vol- |
|  | Mute |  | Mute / Dimmer |
|  | CH- |  | CH- / Page- |
|  | EPG |  | Guide / EPG / -/- |
|  | Option |  | Setup / OPT / |
|  | Up |  | Up |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Down |  | Down |
|  | Menu |  | Menu / Home |





| Original | Recharge |
|--|---|
|  Exit |  Exit / Cancel / Clear |
|  << |  << / Tune- |
|  Play |  Play / Slow |
|  >> |  >> / Tune+ |
|  Rec |  Rec / Rec Mode |
|  Pause |  Pause / Step / Freeze |
|  Stop |  Stop / Hold |
|  File List/[≡i] |  Smart / List |
|  Bookmark/[.,≡] |  Display / Media |
|  Repeat/[≡O] |  Shift + Green / APP / |
|  A<>B/[≡?] |  Shift + Yellow / YouTube / |
|  PIC Size |  Zoom / Size |
|  PIC Mode |  Picture / Format |
|  SND Mode |  Sleep / Timer |
|  M/S |  D.Menu / Top |
| | |
| | |

| Original | Recharge |
|----------|----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

