







































































Original		Rechange		Original		Rechange	
	Power		Power		Mute		Mute
	Source		AV		PR+		Ch +
	Sports		Media		PR-		Ch -
	1		1		CH.LIST		List
	2		2		Menu		Menu
	3		3		Smart HUB		Smart
	4		4		Guide		Guide
	5		5		Tools		Options
	6		6		Info		Info
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	TTX/MIX		Text		Enter		Ok
	PRE-CH		Pre Ch		Return		Back
	Vol+		Vol +		Exit		Exit
	Vol-		Vol -		Red/A		Red



