




































































Original	Rechange	Original	Rechange
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TTX/MIX		Text
	PRE-CH		Pre Ch
	Mute		Mute
	CH-List		Guide
	Vol+		Vol +

Original	Rechange	Original	Rechange
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Tools		Options
	Media.P		Media
	Ball		Smart
	Info		Info
	Exit		Exit
	Return		Back
	Menu		Menu
	Enter		Ok
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	Red		Red
	Green		Green





Original	Recharge	Original	Recharge
 Yellow	 Yellow		
 Blue	 Blue		
 E-Manual	 D. Menu		
 Sleep	 Sleep		
 Micro	 Dual		
 Stop	 Stop		
 <</ <<	 <<		
 Play	 Play		
 Pause	 Pause		
 >>/>>	 >>		

Original	Recharge

