

















Original	Rechange	Original	Rechange
 Power	 On	 Blank	 Hide / Blank
 Up	 Up	 Auto	 Auto / Mode
 Enter	 OK	 Mute	 Mute / Focus
 Down	 Down	 Volume	 Vol +
 Right	 Right	 Keystone	 Vol -
 Left	 Left	 Page Up	 3
 Menu	 Menu / Info	 Page Down	 6 / Comp
 Esc	 Exit / Lamp	 Home	 2
 Reset	 OFF	 End	 5 / VGA2
 Position	 K.S. / PIP		
 Freeze	 Pict / Freeze		
 Magnify On	 KS Up		
 Magnify Off	 KS Down		
 Search	 SRC / Search		
 Video	 8 / Video		
 RGB	 1 / Point		
 Aspect	 Aspect / Re-Sync		

