







































































Original		Rechange		Original		Rechange	
	Power		Power		6		6
	Tv/TXT		Text		7		7
	Input		AV		8		8
	OK		Ok		9		9
	Up		Up		0		0
	Down		Down		Back		Back
	Right		Right		FAV		Shift + Pre Ch
	Left		Left		Menu		Menu
	Vol+		Vol +		Exit		Exit
	Vol-		Vol -		Nicam/A2		Shift + Guide
	CH+		Ch +		Display		Shift + Info
	CH-		Ch -		Mute		Mute
	1		1		Picture		Format
	2		2		Sound		Dual
	3		3		Sleep		Sleep
	4		4		Subtitle		Subt
	5		5		EPG		Guide



