











































































| Original  |        | Rechange  |                   | Original  |                | Rechange  |                          |
|---|--------|---|-------------------|---|----------------|---|--------------------------|
|    | Power  |    | Power             |    | 0              |    | 0                        |
|    | [≡]    |    | Text / Goto       |    | Source         |    | AV / Input / RDS         |
|    | [≡?]   |    | D.Menu / Top      |    | ATV            |    | Shift + Smart / List     |
|    | [...]  |    | Subtitle / EQ     |    | DTV            |    | Shift + Display / Media  |
|    | [≡+]   |    | Eject / Surround  |    | EPG            |    | Guide / EPG / -/-        |
|    | [≡o]   |    | Sound / Title     |    | Radio          |    | TV/Radio /               |
|    | [≡◆]   |    | Zoom / Size       |    | I/II/I+II/▼/O) |    | Audio / Lang I/II        |
|    | 1      |    | 1                 |    | Vol+           |    | Vol+                     |
|    | 2      |    | 2                 |    | P+             |    | CH+ / Page+              |
|    | 3      |    | 3                 |    | P.Info         |    | Display / Media          |
|   | 4      |   | 4                 |   | Mute           |   | Mute / Dimmer            |
|  | 5      |  | 5                 |  | Vol-           |  | Vol-                     |
|  | 6      |  | 6                 |  | P-             |  | CH- / Page-              |
|  | 7      |  | 7                 |  | [i+]           |  | Info / Angle             |
|  | 8      |  | 8                 |  | [<>]           |  | Picture / Format         |
|  | 9      |  | 9                 |  | Sleep          |  | Sleep / Timer            |
|  | Recall |  | Fav / Marker / PC |  | AV Mode        |  | Shift + AV / Input / RDS |





| Original   | Recharge  | Original   | Recharge   |
|--|---|--|--|
|  Menu               |  Menu / Home                   |  Option   |  Setup / OPT /  |
|  Up                 |  Up                            |  Rec      |  Rec / Rec Mode |
|  Left               |  Left                          |  Rec Stop |  Shift + Stop / |
|  OK                 |  OK                            |  Stop     |  Stop / Hold    |
|  Right              |  Right                         |  |  |
|  End                |  Exit / Cancel / Clear         |  |  |
|  Down               |  Down                          |  |  |
|  Back               |  Back / Return                 |  |  |
|  Red                |  Red / Netflix / Search        |  |  |
|  Green             |  Green / APP / Repeat         |  |  |
|  Yellow           |  Yellow / YouTube / Repeat   |  |  |
|  Blue             |  Blue / Prime Video / Random |  |  |
|  Action           |  Smart / List                |  |  |
|  Power Aquos Link |  Shift + Power               |  |  |
|  <<               |  << / Tune-                  |  |  |
|  Play             |  Play / Slow                 |  |  |
|  >>               |  >> / Tune+                  |  |  |

