

































Original		Rechange		Original		Rechange	
	Power		Power				
	Back		Back				
	Home		Smart				
	OK		Ok				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	Vol+		Vol +				
	Vol-		Vol -				
	P+		Ch +				
	P-		Ch -				
	Mute		Mute				
	[?]		Guide				
	My APPS		Media				

