











































































































| Original | | Recharge | | Original | | Recharge | |
|---|------------|---|---------|---|----------------------|---|--------------|
|  | Standby/On |  | Power |  | I<< |  | I<< |
|  | 1 |  | 1 |  | >>I |  | >>I |
|  | 2 |  | 2 |  | Play |  | Play |
|  | 3 |  | 3 |  | Stop |  | Stop |
|  | 4 |  | 4 |  | << |  | << |
|  | 5 |  | 5 |  | >> |  | >> |
|  | 6 |  | 6 |  | Mute |  | Mute |
|  | 7 |  | 7 |  | Prog+ |  | Ch + |
|  | 8 |  | 8 |  | Prog- |  | Ch - |
|  | 9 |  | 9 |  | Vol+ |  | Vol + |
|  | 0 |  | 0 |  | Vol- |  | Vol - |
|  | Tv/DVD |  | TV/R |  | Menu |  | Menu |
|  | Open/Close |  | Eject |  | Return |  | Back |
|  | DTV/Analog |  | Smart |  | Exit |  | Exit |
|  | Input Sel |  | AV |  | Title List/Disc Menu |  | Media |
|  | Copy |  | Options |  | Play List/Title Menu |  | Shift + Menu |
|  | Pause |  | Pause |  | Red |  | Red |


































| Original | Rechange |
|--|---|
|  Green |  Green |
|  Yellow |  Yellow |
|  Blue |  Blue |
|  Guide |  Guide |
|  Info |  Info |
|  Subtitle |  Subt |
|  Text |  Text |
|  Tv/Radio |  Sleep |
|  FAV List |  Pre Ch |
|  Marker |  Shift + Options |
|  Rec |  Rec |
|  Audio |  Dual |
|  Rec Mode |  Shift + Rec |
|  Rec |  Format |
|  Repeat |  Shift + Text |
|  OK |  Ok |
|  Up |  Up |

| Original | Rechange |
|---|---|
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  USB |  Shift + Media |
|  Timer |  Shift + AV |
|  HDD |  Shift + Smart |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

























































| | Original | Rechange | Original | Rechange |
|---|---------------|---|----------|----------|
|  | Input Sel |  | | AV |
|  | 1 |  | | 1 |
|  | 2 |  | | 2 |
|  | 3 |  | | 3 |
|  | 4 |  | | 4 |
|  | 5 |  | | 5 |
|  | 6 |  | | 6 |
|  | 7 |  | | 7 |
|  | 8 |  | | 8 |
|  | 9 |  | | 9 |
|  | 0 |  | | 0 |
|  | Prog+ |  | | Ch + |
|  | Prog- |  | | Ch - |
|  | Standby/On TV |  | | Power |
|  | Mute Tv |  | | Mute |
|  | Tv Vol+ |  | | Vol + |
|  | Tv Vol- |  | | Vol - |





| | Original | Rechange | | Original | Rechange |
|---|------------|---|---------|---|----------------------|
|  | Standby/On |  | Power |  | I<< |
|  | 1 |  | 1 |  | >>I |
|  | 2 |  | 2 |  | Play |
|  | 3 |  | 3 |  | Stop |
|  | 4 |  | 4 |  | << |
|  | 5 |  | 5 |  | >> |
|  | 6 |  | 6 |  | Prog+ |
|  | 7 |  | 7 |  | Prog- |
|  | 8 |  | 8 |  | Menu |
|  | 9 |  | 9 |  | Return |
|  | 0 |  | 0 |  | Exit |
|  | Tv/DVD |  | TV/R |  | Title List/Disc Menu |
|  | Open/Close |  | Eject |  | Play List/Title Menu |
|  | DTV/Analog |  | Smart |  | Red |
|  | Input Sel |  | AV |  | Green |
|  | Copy |  | Options |  | Yellow |
|  | Pause |  | Pause |  | Blue |
| | | | |  | Shift + Menu |





| Original | Recharge | Original | Recharge |
|----------|--------------------|----------|------------------|
| Guide | Guide | USB | + Shift + Media |
| Info | Info | Timer | + Shift + AV |
| Subtitle | Subt | HDD | + Shift + Smart |
| Text | Text | | |
| Tv/Radio | D. Menu | | |
| FAV List | Pre Ch | | |
| Marker | + Shift + Options | | |
| Rec | Rec | | |
| Audio | Dual | | |
| Rec Mode | + Shift + Rec | | |
| Rec | Format | | |
| Repeat | + Shift + Text | | |
| OK | Ok | | |
| Up | Up | | |
| Down | Down | | |
| Right | Right | | |
| Left | Left | | |

