







































































Original		Recharge		Original		Recharge	
	Standby		Power		9		9
	Open/Close		Eject		0		0
	Angle		Format		Random		D. Menu
	Info/Display		Info		Audio		Dual
	Q-Play/Tv/Radio		TV/R		Vol+		Vol +
	PN/EPG		Guide		Vol-		Vol -
	Search/TTX		Text		Stop		Stop
	PBC/List		List		Play		Play
	Subtitle		Subt		Pause		Pause
	1		1		Prev		I<<
	2		2		Red		Red
	3		3		Green		Green
	4		4		Yellow		Yellow
	5		5		Blue		Blue
	6		6		Next		>>I
	7		7		Rew		<<
	8		8		FF		>>



