



Original	Recharge
 Power	 Power
 Mute	 Mute
 Display	 Shift + Info
 TV	 TV/R
 PC	 Smart
 Scart	 AV
 Video/S-V	 Media
 Component	 Options
 Sound	 Dual
 Exit	 Exit
 APC	 Guide
 ARC	 Shift + Pre Ch
 Reset	 Back
 Sleep	 Sleep
 Teletext	 Text
 Up	 Up
 P+	 Ch +

Original	Recharge
 P-	 Ch -
 Down	 Down
 Right	 Right
 Vol+	 Vol +
 Left	 Left
 Vol-	 Vol -
 Enter	 Ok
 Menu	 Menu
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 [≡i]	 Info
 1	 1
 [+]	 Shift + Options
 2	 2
 [≡x]	 Shift + TV/R





Original		Recharge	
	3		3
	[≡?]		List
	4		4
	[◆]		Shift + 3D
	5		5
	Position		Subt
	6		6
	Size		Format
	7		7
	[O]		Shift + Subt
	8		8
	PIP Source		<<
	9		9
	PIP Source Up		>>
	0		0
	On/Off		3D
	+100		Shift + Guide

Original		Recharge	
	RTN		Pre Ch

