



Original	Rechange	Original	Rechange
Power	Power	Up	Up
[≡i]/Info	Info	Down	Down
Mute	Mute	Right	Right
1	1	Left	Left
2	2	Enter	Ok
3	3	Index	Media
4	4	List	List
5	5	CH+	Ch +
6	6	CH-	Ch -
7	7	Vol+	Vol +
8	8	Vol-	Vol -
9	9	♥	Pre Ch
0	0	Sleep	Sleep
[≡?]/Source	AV	EPG	Guide
(OI/II)/Audio	Dual	Recall	Back
Menu	Menu	Red	Red
Exit	Exit	<<	<<

Original	Rechange	Original	Rechange
Power	Power	Up	Up
[≡i]/Info	Info	Down	Down
Mute	Mute	Right	Right
1	1	Left	Left
2	2	Enter	Ok
3	3	Index	Media
4	4	List	List
5	5	CH+	Ch +
6	6	CH-	Ch -
7	7	Vol+	Vol +
8	8	Vol-	Vol -
9	9	♥	Pre Ch
0	0	Sleep	Sleep
[≡?]/Source	AV	EPG	Guide
(OI/II)/Audio	Dual	Recall	Back
Menu	Menu	Red	Red
Exit	Exit	<<	<<





	Original	Rechange	Original	Rechange
	>>		>>	
	Green		Green	
	Yellow		Yellow	
	l<<		l<<	
	>>l		>>l	
	Blue		Blue	
	[≡]		Text	
	Play		Play	
	Pause		Pause	
	Stop/Still		Stop	
	[≡+]		Format	
	Radio		TV/R	
	[≡◆]/[+]		3D	
	[≡x]		Options	
	[≡O]/Subtitle		Subt	
	DMP		Smart	
	Rec		Rec	

