







































































Original		Rechange		Original		Rechange	
	Power		Power		Left		Left
	Mute		Mute		OK		Ok
	1		1		P+		Ch +
	2		2		P-		Ch -
	3		3		Vol+		Vol +
	4		4		Vol-		Vol -
	5		5		SAT		Smart
	6		6		FAV		Pre Ch
	7		7		EPG		Guide
	8		8		[]		Dual
	9		9		Tv/AV		AV
	0		0		Play		Play
	Menu		Menu		Pause		Pause
	Exit		Exit		Back		Back
	Up/CH+		Up		UHF		TV/R
	Down/CH-		Down		i		Info
	Right		Right		PAL/NTSC		Format



