







































































Original		Rechange		Original		Rechange	
	Power		Power		P.Mode		Format
	Mute		Mute		OK		Ok
	Q.View		Options		-		Subt
	Info		Info		Up		Up
	Input		AV		Down		Down
	Exit		Exit		Right		Right
	1		1		Left		Left
	2		2		Menu		Menu
	3		3		CH+		Ch +
	4		4		CH-		Ch -
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		CC		Text
	8		8		Sleep		Sleep
	9		9		S.Mode		Dual
	0		0		Guide		Guide
	SAP		3D		ARC		TV/R





Original	Recharge	Original	Recharge
CH.LIST	CH.List	DISC NAV LIST	List
FAV.LIST	FAV.List	FAV PRE-CH	Pre Ch

